
Non-Bearing 8" CMU wall Lintel - TMS 402 ASD

- Assumptions:

* 85 psf for Solid Grouted 8" CMU wall weight; 45 psf for Hollow 8" CMU wall weight



Width of Wall Opening - Clear Span

Lc =

12 ft.

Width of CMU Wall Pier at Lintel Support

bs =

2 ft.

Height of Lintel Beam - Solid Grouted CMU Depth

h =

2 ft.

Total Height of CMU Wall above Opening

H =

4 ft.

Calculate

Reset

The Effective Span Length:

Le = 14.00 ft.

The Effective Beam Depth:


d = 1.75 ft.

The Uniform Load of CMU Wall above Opening:

w = 260.00 lb/ft

The Maximum Bending Moment:

M = 6.37 ft-kips



Tension Reinforcement Area (in²)

_	
Λ ~	_
A S	_

2 - #4 = 0.4 in2

Specified Masonry Compressive Strength

f'm =

1500

psi

Yeild Strength of Reinforcement

60,000 psi - Grade 60

Calculate

Reset

The Allowable Compressive Stress in Masonry:

Fb = 675.0 psi

The Allowable Tensile Stress of Rebar:

Fs = 32000.0 psi

The Tension Reinforcement Ratio:

rho = 0.00250

The Modular Ratio - Es/Em:

n = 21.48148

The Neutral Axis Depth Factor:

k = 0.2782

The Lever Arm Factor:

j = 0.907

The Maximum Masonry Stress:

 $f_m = 179.99 \text{ psi}$

Stress Ratio:

$$f_m/Fb = 0.27$$

The Reinforcement Stress:

$$f_s = 10030.24 \text{ psi}$$

$$f_s/Fs = 0.31$$